

SEL[®] SEL-2523 Configurable Labels

Overview

The SEL-2523 Configurable Labels Kit provides the materials and information needed to customize the alarm points on the front panel. *Figure 1* shows the pocket areas and openings.





Figure 1 Typical SEL-2523 Configurable Label Areas

The SEL-2523 features a versatile front panel that you can customize for your needs. The SEL-2523 features slide-in labels for custom alarm point window LED designations that match custom alarm point LED logic. Use the slide-in labels to mark the LEDs with these custom names.

The SEL-2523 comes with pre-printed labels. Alternatively, you can write on the back side of the pre-printed labels, use the blank labels provided in this kit, or print your own customized labels.

If you need additional configurable label kits (part number 9260040), contact your Technical Service Center or the SEL factory to obtain these kits (see *Factory Assistance on page 3*).

Removing Configurable Labels



Use the label removal tool to remove labels from the front-panel pockets.

- Step 1. Slide the tip of the tool under the label at the pocket opening (see *Figure 1* for example opening locations).
- Step 2. Push the exposed edge of the label against the label removal tool while pulling out both the label and label removal tool.

Creating Laser-Printed Labels

NOTE: The template is a Word 2000 file. The default template font is from the Arial family. You can use this font or choose a different font that is available on your computer system.

NOTE: You can adjust the font size to accommodate more text within the cell.

Use the following procedure to create laser-printed labels. You can find these files on the SEL website (www.selinc.com). In addition, the label template files are included on the SEL-2523 Product Literature CD.

Step 1. Open the appropriate Microsoft® Word template.

Step 2. Fill in the fields.

Use the Tab and Arrow keys or your mouse to move from field to field. Field space is limited; only the text that displays on the screen prints on the label.

Save the file often to preserve your work in progress.

Step 3. Test the position of the label text by printing the template file to plain paper.

- a. From the document, select **File > Print > OK**.
- b. Examine the printed sheet for proper alignment. Carefully compare the printed page to the perforated stock sheets.
- c. If the printed sheet is not aligned properly, proceed to *Step 4*.
- d. If the labels appear as desired, proceed to *Step 5*.

Step 4. Make adjustments to margin settings, as necessary, to print in the proper location on the test sheet.

- a. Use the **File > Page Setup** menu to adjust only the top or left margins as needed to correct the alignment.
DO NOT adjust the right or bottom margins.
- b. Do another test print on plain paper.
- c. Examine the label position.
- d. Repeat as necessary until the alignment is correct.

Step 5. Print the labels on the perforated stock sheets.

If the labels printed incorrectly, repeat this procedure beginning with *Step 3*.

Step 6. Fold and tear the perforated edges of the stock paper to remove the labels from the sheet.

Step 7. Remove the existing labels from the front-panel label pockets with the label removal tool.

Step 8. Insert the newly created labels in the appropriate pockets on the device front panel.

NOTE: Place the perforated stock sheet in the printer tray as indicated by the printer (either face up or face down).

Also, if your printer has duplex capability, be sure to set the printer to print single sided.

Factory Assistance

We appreciate your interest in SEL products and services. If you have questions or comments, please contact us at:

Schweitzer Engineering Laboratories, Inc.
2350 NE Hopkins Court
Pullman, WA 99163-5603 USA
Telephone: +1.509.332.1890
Fax: +1.509.332.7990
Internet: www.selinc.com
Email: info@selinc.com

© 2008 by Schweitzer Engineering Laboratories, Inc. All rights reserved.

All brand or product names appearing in this document are the trademark or registered trademark of their respective holders. No SEL trademarks may be used without written permission. SEL products appearing in this document may be covered by US and Foreign patents.

Schweitzer Engineering Laboratories, Inc. reserves all rights and benefits afforded under federal and international copyright and patent laws in its products, including without limitation software, firmware, and documentation.

The information in this document is provided for informational use only and is subject to change without notice. Schweitzer Engineering Laboratories, Inc. has approved only the English language document.

This product is covered by the standard SEL 10-year warranty. For warranty details, visit www.selinc.com or contact your customer service representative.

SCHWEITZER ENGINEERING LABORATORIES

2350 NE Hopkins Court • Pullman, WA 99163-5603 USA

Phone: +1.509.332.1890 • Fax: +1.509.332.7990

Internet: www.selinc.com • E-mail: info@selinc.com

