

Instructions for Creating Part Numbers

Note: Please consult with your SEL representative on available displays and other configuration options before ordering.

To create a part number, select one code (in bold) from each column. List option codes in the order they appear, left to right.

BTRI_IR Overhead BEACON® Timed-Reset Fault Indicator						
BEACON Timed-Reset Fault Indicator	Nominal Trip Rating		Inrush Restraint	Timed-Reset Duration		Options
BTRI	0050	50 A	IR	2	2 hrs	— No Options
	0100	100 A		4	4 hrs	DT Delayed Trip (24 ms)
	0200	200 A		8	8 hrs	N Nonreplaceable Battery
	0300	300 A				
	0400	400 A				
	0600	600 A				
	0800	800 A				
	1000	1,000 A				
	1200	1,200 A				

Example part number: BTRI0100IR2N

The example part number is for a BTRI_IR with a 100 A nominal trip rating, inrush restraint, a two-hour reset duration, and a nonreplaceable battery.