

INSTRUCTIONS FOR CREATING PART NUMBERS

1. Select one code (in bold) from each column. List option codes in the order that they appear in the column.
2. Follow your usual process to issue a purchase order, or complete a specification for standards.

OVERHEAD CURRENT RESET (CRD)				
Current Reset Designation	Nominal Trip Rating		Inrush Restraint	Options
CRD	0100	100 A	IR	— No Options
	0200	200 A		DT Delayed Trip (24 ms)
	0300	300 A		
	0400	400 A		
	0600	600 A		
	0800	800 A		
	1000	1000 A		
	1200	1200 A		

Example Part Number: **CRD0200IRD**