

**ACCESSORY BLOCK CONFIGURATION TABLE**

Pole #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
<b>Configuration Number</b>																				
AB01	S	S	S	S	S	S	S	X	X	X	X	X	X	X	X	X	X	X	X	X
AB02	V	V	V	V	V	V	V	X	X	X	X	X	X	X	X	X	X	X	X	X
AB03	C	—	C	—	C	—	C	S	S	S	X	X	X	X	X	X	X	X	X	X
AB04	C	—	C	—	C	—	C	V	V	V	X	X	X	X	X	X	X	X	X	X
AB05	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	X	X	X	X	X
AB06	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	X	X	X	X	X
AB07	C	—	C	—	C	—	C	C	—	C	—	C	—	C	—	C	S	S	X	X
AB08	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V
AB09	C	—	C	—	C	—	C	C	—	C	—	C	—	C	—	C	C	—	C	—
AB10	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S	S

- C** CURRENT
- V** VOLTAGE
- S** SIGNAL/TRCP
- T** TEST SIGNAL
- X** NOT POPULATED
- SHORTING BRIDGE