

SEL-351RS Kestrel

Single Phase Recloser Control

Standard with Ethernet, IEEE C37.118 Synchrophasor Measurement, DNP3 Outstation, Modbus[®] TCP/RTU, Telnet, FTP, Web Server, SNTP, acSELeRator QuickSet[®] SEL-5030 Software⁽¹⁾

Part Number: **0 3 5 1 R S 0 2** **B** **1 X**

Firmware

Standard **0**

Recloser Interface

G&W Viper-SP, or Elastimold MVR (10-Pin) **2**

Enclosure

Lift-To-Open, Painted Aluminum	1
Swing Open, Painted Aluminum with 3-Point Latch*	2
Swing Open, Painted Aluminum with 3-Point Latch and Convenience Outlet*	4
Swing Open, Painted Aluminum with 3-Point Latch and GFCI Outlet*	C

Conformal Coat

None	X
Conformal Coated Circuit Boards*	1

User Interface

Standard plus Configurable Labels and USB⁽²⁾ **B**

User Inputs/Outputs

(1) Input (12 Vdc), (1) Standard Output, and (1) Alarm Output	1
(4) Inputs (12 Vdc), (5) Standard Outputs, and (1) Alarm Output*	2

Communications Interface

(1)100Base-FX MM LC, EIA-485*	D
(2)10/100Base-T, EIA-485	E
(2)100Base-FX MM LC, EIA-485*	F

Communications Protocols

Standard Protocols	1
Standard Protocols plus IEC 61850*	2

Power Supply

120/230 Vac or 125/250 Vdc **1**

Battery Option

12 V, 16 Ahr	1
12 V, 40 Ahr*	2

Installed Accessories ⁽³⁾

None	X	X
Heater*	1	0
3-Pin Receptacle for Incoming Power*	1	1

SEL-2401 Satellite-Synchronized Clock*																					1	6																			
SEL-2925 BLUETOOTH® Serial Adapter*																								1	C																
SEL-3031 Serial Radio Transceiver (30310W01XXX) Accessory ^{(4)*}																										1	8														
SEL-3060 Ethernet Radio ⁽⁴⁾																													1	9											
SEL-2401 Satellite-Synchronized Clock and SEL-3060 Ethernet Radio ⁽⁴⁾																															A	8									
Accessory Mounting Kit ^{(4)*}																																3	0								
Heater and 3-Pin Receptacle for Incoming Power*																																		A	0						
Heater and SEL-2401 Satellite-Synchronized Clock*																																			A	2					
3-Pin Receptacle for Incoming Power and SEL-2401 Satellite-Synchronized Clock*																																				A	4				
3-Pin Receptacle for Incoming Power, Heater and SEL-2401 Satellite Synchronized Clock*																																					A	7			
Heater and Accessory Mounting Kit ^{(4)*}																																					C	0			
3-Pin Receptacle for Incoming Power and Accessory Mounting Kit ^{(4)*}																																						C	1		
Heater, 3-Pin Receptacle for Incoming Power and Accessory Mounting Kit ^{(4)*}																																							C	2	

Packaged Accessories⁽⁵⁾

None																																									X
(1) Security Sleeve (1-1/2" diameter)*																																									1
(2) Security Sleeves (1-1/2" diameter)*																																									2
(3) Security Sleeves (1-1/2" diameter)*																																									3

Accessories (Shipped Separately)

Security Sleeve (1 1/2" diameter)*	9	2	5	0	1	9	7																																				
3-Pin Receptacle for Incoming Power*	9	2	5	0	1	9	4																																				
SEL-2401 Satellite-Synchronized Clock*	9	2	5	0	1	9	6																																				
Accessory Mounting Kit*	9	2	5	0	2	1	5																																				
16 Ahr Replacement Battery Kit*	9	1	5	9	0	0	2	0	0																																		
40 Ahr Replacement Battery Kit*	9	1	5	9	0	0	1	9	9																																		
10-Pin Control Cable	C	5	2	5																																							
Control Cable, 10-Pin Female to Female	C	5	5	4																																							

* Additional Cost

- ⁽¹⁾ Download ACSELERATOR QuickSet SEL-5030 Software free at <http://www.selinc.com/software/solutions/>. ACSELERATOR QuickSet on CD (503001WX4) is available upon request.
- ⁽²⁾ A configuration kit (9260063) is provided (packaged in the shipping box).
- ⁽³⁾ Enter the two-digit Accessory Code in the last two columns of the part number for new units. If accessories are being ordered for previously purchased units, use the 7 digit accessory part number).
- ⁽⁴⁾ Available for Swing Open Enclosures only.
- ⁽⁵⁾ Accessories packaged and shipped with 351RS, but are not installed at the SEL factory.

Note: The SEL-351RS comes standard with a CD manual. A printed Instruction Manual is available upon request.

Making Electric Power Safer, More Reliable, and More Economical®

SEL SCHWEITZER ENGINEERING LABORATORIES, INC.

2350 NE Hopkins Court - Pullman, WA 99163 USA
Phone: +1.509.332.1890 - Fax: +1.509.332.7990