## **SEL-700G**

### **Generator Protection Relay**



# Comprehensive protection for large, medium, and small generators

- Provide primary and backup generator protection with current, voltage, frequency, distance, power, and out-of-step elements.
- Achieve 100 percent stator ground protection with full winding coverage.
- Use the automatic synchronizer and event reports to analyze generator startup, shutdown, or system faults.
- Support installations with low-energy analog (LEA) voltage sensors, Rogowski coils, and low-power current transformers (LPCTs).
- Improve network recovery via alternate paths in a network with the Rapid Spanning Tree Protocol (RSTP).



### **Functional Overview**



#### Model Comparison Table

You can customize the SEL-700G for specific applications by selecting preconfigured model options.

Model	Application
SEL-700G0 or SEL-700G0+	Basic generator protection
SEL-700G1 or SEL-700G1+	Full generator protection
SEL-700GT	Intertie protection
SEL-700GT+	Intertie and generator protection
SEL-700GW	Basic dual-feeder protection





#### ANSI Numbers/Acronyms and Functions

21C/51VC	Compensator Distance, Voltage Restrained/Controlled Time Overcurrent
24	Volts/Hertz
25G	Generator Synchronism Check
25T	Tie Synchronism Check
27	Undervoltage
271	Inverse-Time Undervoltage
275	Synchronism Undervoltage
32	Directional Power
40	Loss of Field
46	Current Unbalance
49R	Thermal Overload (Resistance Temperature Detector [RTD])
49T	Thermal Model
50N	Neutral Overcurrent
50 (P,G,Q)	Overcurrent (Phase, Ground, Neg. Seq.)
51 (P,G,Q)	Time Overcurrent (Phase, Ground, Neg. Seq.)
51C	Voltage-Controlled Phase Time Overcurrent
51N	Neutral Time Overcurrent
51V	Voltage-Restrained Phase Time Overcurrent
591	Inverse-Time Overvoltage
59N (64G1)	Neutral Overvoltage
59S	Synchronism Overvoltage
59 (P,G,Q)	Overvoltage (Phase, Ground, Neg. Seq.)
60	Loss of Potential
64F	Field Ground
64G	100% Stator Ground
67 (P,G,Q)	Directional Overcurrent (Phase, Ground, Neg. Seq.)
67N	Directional Neutral Overcurrent

Continued		
77	Telemetering Device	
78	Out of Step	
78VS	Vector Shift	
81 (O,U,R)	Frequency (Over, Under, Rate)	
87	Three-Phase Current Differential	
87N	Neutral Current Differential	
REF	Restricted Earth Fault	

Additional	l Functions
52PB	Pushbutton Trip/Close
85 RIO	SEL MIRRORED BITS <sup>®</sup> Communications
BF	Breaker Failure
BRM	Breaker Wear Monitor
DFR	Event Reports
ENV	SEL-2600
НМІ	Operator Interface
LDP	Load Data Profiling
LEA	LEA Voltage Sensor Inputs and Rogowski Coil/LPCT Inputs
LGC	SELogic <sup>®</sup> Control Equations
MET	High-Accuracy Metering
PMU	Synchrophasors
RTU	Remote Terminal Unit
SER	Sequential Events Recorder
WEB	Web Server



### **Key Features**

#### **Comprehensive Generator Protection**

Connect the SEL-700G Generator Protection Relay across small, medium, or large generators for complete primary and backup protection. Adding the neutral voltage connection provides 100 percent stator ground protection, based on fundamental-frequency and third-harmonic neutral voltage measurements. Connecting the neutral current input provides protection for solidly grounded or resistance-grounded generators.

#### Automatic Synchronizer

Replace external generator control and synchronizer relays with the built-in automatic synchronizer function. The SEL-700G automatically synchronizes the frequency, voltage, and phase control of the generator with the power system. Generator start reports and the PC-based synchroscope allow you to monitor the generator synchronization. The built-in automatic synchronizer function is available on select SEL-700G models.

#### LEA Sensor Inputs

The SEL-700G can be ordered with LEA inputs to support medium- and lowvoltage applications that use low-energy voltage sensors and Rogowski coils or other low-power current sensors. Order your device with the combination of LEA current and voltage inputs that suits your application.

#### **Islanding Protection**

Detect islanding conditions using the vector shift function. The vector shift function provides another element of protection for distributed generators connected to the utility network. It operates within three cycles—fast enough to prevent out-of-synchronization reclosing with the network feeders to avoid generator damage.

#### **Easy Communications**

Choose from single or dual copper or fiber-optic Ethernet ports, serial communications, and several protocols, including MIRRORED BITS communications, RSTP, IEC 61850 Edition 2, EtherNet/IP, the IEEE 1588 Precision Time Protocol (PTP) (firmware-based), IEC 60870-5-103, and the Parallel Redundancy Protocol (PRP). Multiple Modbus TCP or Modbus serial sessions are available for custom configuration of your application. You can also use DNP3 serial or DNP3 LAN/WAN protocols. In addition, the IEC 61850 test mode enables in-service testing, which reduces commissioning time.

#### **Breaker Wear Monitoring**

Record accumulated breaker contact wear with the breaker monitor function, which uses the breaker manufacturer's specifications for defining operation limits. The internal monitor tracks the total number of close/open operations and integrates the interrupted current per phase. You can set an alarm to alert operators when measured and accumulated quantities approach maintenance thresholds. This information facilitates proactive breaker maintenance and replacement without underutilizing resources.

#### **Current Differential Protection**

Apply sensitive percentage-restrained current differential elements and an unrestrained element, along with synchronism-check and volts-per-hertz elements, across the entire unit to protect both the generator and the stepup transformer. Optional current differential elements detect stator faults using a secure, sensitive current differential function. Power transformer and CT connection compensation allows you to include the unit step-up transformer in the generator differential zone.

#### Synchrophasor Data

Apply SEL synchrophasors (IEEE C37.118-2005) to turn state estimation into state measurement and to provide early warning of potential system instability. The SEL-700G phasor measurement accuracy meets the IEEE C37.118-2005 Level 1 requirement. Users can also visualize and synchronize system parameters on the device using the available color touchscreen display.

#### Reliable, Rugged Hardware

The SEL-700G operates in extreme conditions, with an operating temperature range of -40° to +85°C (-40° to +185°F). It withstands vibration, electrical surges, fast transients, and extreme temperatures, meeting stringent industry standards. A conformal-coating option for the printed circuit boards provides an additional barrier against airborne contaminants, such as hydrogen sulfide, chlorine, salt, and moisture. In addition, the SEL-700G is ATEX-certified and Underwriters Laboratories (UL) Class I, Division 2 certified for use in hazardous and potentially explosive environments.

### **Product Overview**



Large 2 × 16 character LCD.

### **Touchscreen Overview**



#### **Conventional CT and PT Input Option**



#### LEA Current and Voltage Inputs Option



\*Compliant with IEC 61869-6, -13 standards.

### **Touchscreen Display Features and Functions**

The SEL-700G 5-inch, 800 × 480 color touchscreen display provides a one-line diagram mimic display for bay control and monitoring. You can view metered quantities, phasor diagrams, relay settings, event summaries, target statuses, and SER data.

#### **Bay Screens and Bay Control**

Select from predefined bay screens, or configure as many as five custom bay screens using the ACSELERATOR<sup>®</sup> Bay Screen Builder SEL-5036 Software and ACSELERATOR QuickSet<sup>®</sup> SEL-5030 Software. With the bay screen, you can control as many as two breakers, eight two-position disconnects, and two three-position disconnects and can view analog and digital data in a contextual display.

To control a breaker, simply tap the Bay Screens application on the home screen and then the breaker you want to control.

Next, enter your Level 2 password and tap Submit. The onscreen keyboard allows you to quickly and easily enter passwords, search for Relay Word bits, and enter settings whenever necessary.




Finally, tap Trip or Close to control the breaker. When asked to confirm the action before the operation is completed, choose Yes or No.

#### **Meter Fundamentals**

View the real, reactive, and apparent power of each phase in your system, and monitor the power factor information to determine if the phase current leads or lags the phase voltage.

Fundamental Metering		03/27/2	2018 10:43:10	
5		А	В	С
	PX (kW)	7502	7549	7519
	QX(kVAR)	4089	4069	4081
~	SX (kVA)	8542	8575	8558
~	PFX	0.88 LAG	0.88 LAG	0.88 LAG
				🗙 LR 2AC



#### **Meter Phasors**

View a graphical and textual representation of the realtime voltages and currents in a power system during balanced and unbalanced conditions. By analyzing the phasors, you can determine power system conditions.

#### Meter Energy

Display the real, reactive, and apparent energy metering quantities imported and exported by your system. You can reset the energy values via the display and record the time and date of reset. Whether your system is a net energy producer or consumer, metered quantities accurately account for the power system energy flow.

### Visualize and Control Synchronization

Use the Synchroscope application in the Monitor folder to view a graphical representation of the phasor difference between the bus and the generator or the tie. You can also use the Autosynchronization application in the Control folder to initiate autosynchronization. With the touch of a finger, you can automatically synchronize the frequency, voltage, and phase angle of the generator and connect to the power system. This eliminates the need for expensive external synchronizing equipment.





### Applications

Eliminate the complexity and cost of standalone synchronizer packages. The SEL-700G provides a comprehensive protection and synchronization solution for synchronous generators. Integrating the synchronization capability into the generator protection relay provides the most cost-effective and reliable solution.

The optional SEL-2664 Field Ground Module accurately detects field ground faults whether the generator is operating, stopped, or de-energized.

#### **Unit Protection**

Apply sensitive percentage-restrained current differential elements and an unrestrained element, along with synchronism-check and volts-per-hertz elements, across the entire unit to protect both the generator and the step-up transformer. Harmonic blocking elements protect the unit transformer bushing and end windings while maintaining security for inrush and through-fault conditions.

#### Stator/Field Ground Protection

Adding the neutral voltage connection provides 100 percent stator ground protection for most generators, based on fundamental-frequency and third-harmonic neutral-voltage measurements. Connecting the neutral current input provides protection for solidly grounded or resistance-grounded generators. State-of-the-art voltage injection provided by the SEL-2664 module allows you to monitor field ground insulation resistance. You can protect generators from damage by responding to low field ground insulation resistance warnings.

#### Automatic Generator Control

The SEL generation control system regulates generator power outputs and manages utility interties to maximize system stability, minimize electrical disturbances, and mitigate load-shedding requirements. The SEL-700G in combination with the SEL POWERMAX® Power Management and Control System can balance generator loading, control tie line power flow, and maintain bus voltage.

The automatic MVAR and voltage control system maintains MVAR flows on interties and system bus voltages by controlling load tap changers, generator field and large synchronous motor exciters, synchronous and static condensers, and capacitor banks.





#### Metering and Reporting

View generator automatic synchronizer, SER, and 180-cycle oscillographic event reports in COMTRADE and CEV formats to analyze generator startup, shutdown, or system faults. The SEL-700G measures electrical, thermal, and generator run-time quantities and allows you to retrieve COMTRADE files via the Ethernet File Transfer Protocol (FTP) or IEC 61850 MMS.



#### Autosynchronization

Use the additional, built-in automatic synchronizer function to automatically synchronize the frequency, voltage, and phase angle of the generator and connect to the power system. This eliminates the need for expensive external synchronizing equipment. In addition, you can use a digital app with the available touchscreen display to visualize and synchronize system parameters.



#### **RTD-Based Thermal Protection**

Acquire thermal data for alarm, monitoring, and trip functions in the SEL-700G with a 10 RTD input card or an external 12 RTD SEL-2600 RTD Module.



#### Synchrophasor Measurement

Combine the SEL-700G with an SEL IRIG-B time source to measure the system angle in real time with a timing accuracy of  $\pm 10 \ \mu$ s. You can measure instantaneous voltage and current phase angles in real time to improve system operation with synchrophasor information.



View of system angle at multiple locations.

### Easy to Set and Use

Use QuickSet Software to Set, Monitor, and Control the SEL-700G

With QuickSet, you can:

- Communicate with the SEL-700G through any ASCII terminal, or use the QuickSet graphical user interface.
- Develop settings offline with a menudriven interface and completely documented help screens. You can speed up installation by copying existing settings files and modifying application-specific items.
- Simplify the settings procedure with rules-based architecture to automatically check interrelated settings. Out-of-range or conflicting settings are highlighted for correction.
- Use the AcSELERATOR HMI synchroscope to view the real-time synchronization process.
- Set an HMI pushbutton to initiate the generator synchronization process.



#### Integrated Web Server

Access basic SEL-700G information on a standard Ethernet network with the built-in web server. View the relay status, SER data, metering information, and settings with easy access within a local network. For increased security, web server access requires a relay password and the information is limited to a read-only view. You can also upgrade the relay firmware through the web server.

SEL SCHWEIT	ZER RING TORIES					STATION A RELAY 1
Device Time: Thu Jan 2	27 11:49:16		ACC [Logout ]			1 users logged in
Version	GROUP 1 (SHO)					^
History Sequential Events	Line Configuration					
Recorder Self-Test Status	CTRW := 200 PTRZ := 2000.0	CTRX := 200 VNOMZ := 115 ZOANG := 81 50	PTRY := 20 Z1MAG := 7.	00.0 VNOMY 80 Z1ANG	:= 115 := 84.00	=
Metering	Relay Configuratio	n	EFECC .= 1			
Show Settings Group Protection Automation Port Global Output Front Panel	E21MP := 3 ECVT := N ELOAD := Y E51 := N E32 := AUTO E79 := Y EADV5 := N	E21XP := 3 ECDTD := N E50P := 1 E81 := N ECOMM := N EMANCL := Y	E21MG := 3 ESOTF := Y E50G := N E27 := N EBFL1 := N ELOP := Y1	E21XG E005 E50Q E59 E258K1 EDEM	I = N I = N I = N I = N I = N I = N	
Report Alias	Mho Phase Distance	Element Reach				
DNP	Z1MP := 6.24	Z2MP := 9.36	Z3MP := 1.	87		
Communications	Quad Phase Distanc	e Element Reach				
Targets	XP1 := OFF	XP2 := OFF	XP3 := OF	F		
	Phase Distance Ele	ment Time Delay				
	Z1PD := 0.000	Z2PD := 20.000	Z3PD := 60	. 000		
	Mho Ground Distanc	e Element Reach				
	Z1MG := 6.24	Z2MG := 9.36	Z3MG := 1.	87		
	Zero-Sequence Comp	ensation Factor				
	k0M1 := 0.726	k0A1 := -3.69				_
Copyright @ 2010 Schweitzer Engin	Ground Distance Fl eering Laboratories, Inc. Pullman, Wa	ement Time Delay shington. Al Rights Reserved.				~

#### Use SEL-5601-2 SYNCHROWAVE® Event Software to Retrieve and Display Event Reports Recorded by the SEL-700G

With SYNCHROWAVE software, you can:

- Display event report oscillograms. You can view each report as a plot of magnitude versus time and select analog and digital points to build a custom display.
- Display phase and symmetrical component phasors. Displaying the phasor view of electrical data helps you better understand asymmetrical, threephase faults. You can build a custom plot using per-phase and symmetrical component sequence currents and voltages.
- Retrieve event reports using serial or Ethernet communications links.





#### **Retrofit Replacement Kits**

Easily replace existing generator protection with the SEL-700G and the applicable mounting kit. These kits provide everything needed to replace many existing generator relays with the SEL-700G.

No cutting or drilling is required when you use the optional mounting kits. Replacement of existing protection is quick and easy.

### SEL-700G Options

Current and Voltage Input Cards Model	Model
3 currents, 1 neutral current, 3 voltages (Slot Z)	SEL-700G0
3 currents, 1 neutral current, 3 voltages (Slot Z) and 1 voltage (synchronism check) (Slot E)	SEL-700G0+
3 currents, 1 neutral current, 3 voltages (Slot Z) and 3 currents (Slot E)	SEL-700G1
3 currents, 1 neutral current, 3 voltages (Slot Z) and 3 currents, 1 voltage (synchronism check) (Slot E)	SEL-700G1+
1 neutral current (Slot Z) and 3 currents, 1 voltage (synchronism check), 3 voltages (Slot E)	SEL-700GT
3 currents, 1 neutral current, 3 voltages (Slot Z) and 3 currents, 1 voltage (synchronism check), 3 voltages (Slot E)	SEL-700GT+
3 currents (Slot Z) and 3 voltages (Slot E)	SEL-700GW

#### Optional Communications and I/O Cards

Serial communications card (EIA-232/-485)

3 digital inputs (DI), 4 digital outputs (DO), 14–20 mA analog output (AO)

4 DI, 4 DO

8 DO

8 DI

14 DI

4 DI, 3 DO (2 Form C, 1 Form B)

4 analog inputs (AI)/4 AO

LEA voltage sensor inputs and Rogowski coil/LPCT inputs

10 RTD inputs

### **SEL-700G Specifications**

General	
Displays	2-line × 16-character LCD
	5-inch color touchscreen display, 800 × 480 pixels
AC Current Inputs	5 A or 1 A phase and 5 A or 1 A neutral
Rogowski Coil-Based AC Current Inputs (RJ45)	30 Vrms continuous, ±185 V <sub>peak</sub> , 200 Vac for 10 seconds Compliant with IEC 61869-6, -13 standards
LPCT Inputs (RJ45)	4 Vrms continuous, ±11.3 $V_{\text{peak}}$ , 200 Vac for 10 seconds
AC Voltage Inputs	300 Vac continuous, 600 Vac for 10 seconds
LEA Voltage Inputs	8 Vrms continuous, ±12 $V_{\text{peak}}$ , 200 Vac for 10 seconds
Output Contacts	The relay supports Form A, B, and C outputs.
Optoisolated Control Inputs	DC/AC control signals: 250, 220, 125, 110, 48, or 24 V As many as 26 inputs are allowed in ambient temperatures of 85°C (185°F) or less. As many as 34 inputs are allowed in ambient temperatures of 75°C (167°F) or less. As many as 44 inputs are allowed in ambient temperatures of 65°C (149°F) or less.
Frequency and Phase Rotation	System frequency: 50, 60 Hz Phase rotation: ABC, ACB Frequency tracking: 15—70 Hz (requires ac voltage inputs)
Autosynchronizing	Frequency matching: ±0.1% plus ±4.2 ms at 60 Hz Voltage matching: VAY, VBY, VCY, VABY, VBCY, BCAY, or angle from VAY or VABY
Communications Protocols	SEL (Fast Meter, Fast Operate, and Fast SER), Modbus TCP/IP, Modbus RTU, DNP3, FTP, IRIG-B, Telnet, Simple Network Time Protocol (SNTP), EtherNet/IP, firmware-based IEEE 1588 PTP, IEC 61850 Edition 2, IEC 60870-5-103, PRP, RSTP, MIRRORED BITS communications, and IEEE C37.118-2005 (synchrophasors).
Language Support	English and Spanish
Power Supply	110–250 Vdc or 110–240 Vac Input voltage range: 85–275 Vdc or 85–264 Vac 24–48 Vdc Input voltage range: 19.2–60 Vdc
Operating Temperature	–40° to +85°C (–40° to +185°F) Note: Front-panel display contrast is impaired for temperatures below –20°C (–4°F) and above +70°C (+158°F).
Certifications	To view certifications for the SEL-700G, please visit <b>selinc.com/company/certifications</b> .



Making Electric Power Safer, More Reliable, and More Economical +1.509.332.1890 | info@selinc.com | selinc.com

© 2025 by Schweitzer Engineering Laboratories, Inc. PF00211 • 20250307

