

SEL-387-0, -5, -6

Current Differential and Overcurrent Relay, Standard with 8 Outputs, 6 Inputs, Conventional Terminal Blocks, and ACSELERATOR® QuickSet SEL-5030 Software⁽¹⁾

Part Number:

0	3	8	7					X										X	
---	---	---	---	--	--	--	--	---	--	--	--	--	--	--	--	--	--	---	--

Firmware

Standard								0											X
Standard plus Integration Enhancements with Binary SER								5											
Standard plus Integration Enhancements with Binary SER and Thermal Element*								6											

I/O Board; Chassis

No Additional I/O, 2U								0										X	
Additional 12 Std Outputs, 8 Inputs, 3U*								1										2	
Additional 4 Std Outputs, 16 Inputs, 3U*								6	1									4	
Additional 12 High I/C Outputs, 8 Inputs, 3U*								1										6	

Power Supply

24/48 Vdc																		2	
48/125 Vdc or 125 Vac																		3	
125/250 Vdc or Vac																		4	

Secondary Input Current

1 Amp Phase																		1	
5 Amp Phase																		5	

Mounting

Horizontal Rack Mount																		H	
Horizontal Panel Mount																		3	
Horizontal Projection Panel Mount*																		5	

Conformal Coat

None																		X	
Conformal Coated Circuit Boards*																		2	

Control Input Voltage

24 Vdc																			1
48 Vdc																			2
110 Vdc																			3
125 Vdc																			4
220 Vdc																			5
250 Vdc																			6

Communications Protocol

Standard - SEL ASCII, SEL Compressed ASCII, SEL Distributed Port Switch (LMD), Fast Meter and Fast Operate																			X
Standard plus DNP 3.00 Level 2 Slave (available only in 387-5, -6)*																			1

Accessories

Literature	
SEL-387-0, -5, -6 Printed English Instruction Manual ⁽²⁾	PM387-01
SEL-387-0, -5, -6 Printed Spanish Instruction Manual ⁽²⁾	PM387-07

***Additional Cost**

⁽¹⁾ Download acSELERATOR QuickSet SEL-5030 software for free at <https://www.selinc.com/software/solutions/>. acSELERATOR QuickSet on CD (503001WX4) is available upon request. acSELERATOR QuickSet does not support the SEL-387-0.

⁽²⁾ The SEL-387-0, -5, -6 comes standard with a CD manual. One complimentary printed instruction manual is available upon request with each product purchased.

Making Electric Power Safer, More Reliable, and More Economical®

SEL SCHWEITZER ENGINEERING LABORATORIES, INC.

2350 NE Hopkins Court - Pullman, WA 99163 USA
Phone: +1.509.332.1890 - Fax: +1.509.332.7990