

SEL-387A

Current Differential Relay, Standard with 8 Outputs, 6 Inputs, Conventional Terminal Blocks, and ACSELERATOR® QuickSet SEL-5030 Software⁽¹⁾

Part Number:

0	3	8	7	A	0					X		
---	---	---	---	---	---	--	--	--	--	---	--	--

Firmware

Standard					0							
----------	--	--	--	--	---	--	--	--	--	--	--	--

Conformal Coat

None					1							
------	--	--	--	--	---	--	--	--	--	--	--	--

Conformal Coated Circuit Boards*					2							
----------------------------------	--	--	--	--	---	--	--	--	--	--	--	--

I/O Board; Chassis; Mounting

No Additional I/O, 2U	Horizontal Rack Mount					0	H	X				
	Horizontal Panel Mount					0	3	X				
	Horizontal Projection Panel Mount*					0	5	X				
Additional 12 Std Outputs, 8 Inputs, 3U	Horizontal Rack Mount*					1	H	2				
	Horizontal Panel Mount*					1	3	2				
	Horizontal Projection Panel Mount*					1	5	2				
Additional 4 Std Outputs, 16 Inputs; 3U	Horizontal Rack Mount*					1	H	4				
	Horizontal Panel Mount*					1	3	4				
	Horizontal Projection Panel Mount*					1	5	4				
Additional 12 High I/C Outputs, 8 Inputs, 3U	Horizontal Rack Mount*					1	H	6				
	Horizontal Panel Mount*					1	3	6				
	Horizontal Projection Panel Mount*					1	5	6				

Power Supply

24/48 Vdc								2				
-----------	--	--	--	--	--	--	--	---	--	--	--	--

48/125 Vdc or 125 Vac								3				
-----------------------	--	--	--	--	--	--	--	---	--	--	--	--

125/250 Vdc or Vac								4				
--------------------	--	--	--	--	--	--	--	---	--	--	--	--

Secondary Input Current

1 Amp Phase										1		
-------------	--	--	--	--	--	--	--	--	--	---	--	--

5 Amp Phase										5		
-------------	--	--	--	--	--	--	--	--	--	---	--	--

1 Amp Phase, 1 Amp Neutral, including 2xREF Elements*										2		
---	--	--	--	--	--	--	--	--	--	---	--	--

5 Amp Phase, 5 Amp Neutral, including 2xREF Elements*										3		
---	--	--	--	--	--	--	--	--	--	---	--	--

Control Input Voltage

24 Vdc										1		
--------	--	--	--	--	--	--	--	--	--	---	--	--

48 Vdc										2		
--------	--	--	--	--	--	--	--	--	--	---	--	--

110 Vdc										3		
---------	--	--	--	--	--	--	--	--	--	---	--	--

125 Vdc										4		
---------	--	--	--	--	--	--	--	--	--	---	--	--

220 Vdc										5		
---------	--	--	--	--	--	--	--	--	--	---	--	--

250 Vdc										6		
---------	--	--	--	--	--	--	--	--	--	---	--	--

Communications Protocol

Standard	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Standard plus DNP 3.00 Level 2 Slave*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	1

Accessories

Literature															
Printed Instruction Manual ⁽²⁾														P M 3 8 7 A - 0 1	

*Additional Cost

⁽¹⁾ Download ACCELERATOR QuickSet SEL-5030 software for free at <https://www.selinc.com/software/solutions>. ACCELERATORQuickSet on CD (503001WX4) is available upon request.

⁽²⁾ The SEL-387A comes standard with a CD manual. One complimentary printed manual is available upon request with each product purchased.

Making Electric Power Safer, More Reliable, and More Economical®

SEL SCHWEITZER ENGINEERING LABORATORIES, INC.

2350 NE Hopkins Court - Pullman, WA 99163 USA
 Phone: +1.509.332.1890 - Fax: +1.509.332.7990