

| | |
|--|---|
| SEL-C273 EIA-232 Serial Cable, SEL Relay to SEL Communications Processor (with IRIG-B signal) (configurable length)* | Please see Online MOT or contact SEL REP or CSR for ordering information. |
| SEL-C805 200 µm Multimode Fiber-Optic Cable (configurable length)* | Please see Online MOT or contact SEL REP or CSR for ordering information. |
| SEL-C807 62.5/200µm Multimode Fiber-Optic Cable (configurable length)* | Please see Online MOT or contact SEL REP or CSR for ordering information. |
| SEL-C808 62.5/125 µm Multimode Fiber-Optic Cable* | Please see Online MOT or contact SEL REP or CSR for ordering information. |
| SEL-CA605 CAT5e, Shielded Twisted Pair (STP) Ethernet Cable* | Please see Online MOT or contact SEL REP or CSR for ordering information. |

Additional Information

- Base unit includes slots A, B (EIA-232), Z, HMI, and Front EIA-232 Port.
- The protocols SNMP and Modbus TCP are included in the STANDARD offering with Ethernet option.
- DNP3 LAN/WAN are included with DNP3 and Ethernet options.
- Download ACSELERATOR QuickSet SEL-5030 software for free at <https://www.selinc.com/software/solutions/>. ACSELERATOR QuickSet on CD (503001WX4) is available upon request.
- The SEL-787-2,-3,-4 comes standard with a CD manual. One complimentary printed instruction manual is available upon request with each product purchased.
- A configuration kit is provided for the front panel configurable labels (packaged in the shipping box). For additional kits, order SEL part number 9260136 (2 Sheet Kit) or 9260137 (25 Sheet Kit).
- For additional remote I/O capability, order SEL-2505 Remote I/O Module that is SEL-2812 compatible (ST option only).
- Order external AC powered RTD module SEL-2600A or external DC powered RTD module SEL-2600D using WI-5997 to interface remote external resistive temperature devices (RTD) or use internal RTD inputs option in Slot D.
- The SEL-787-2,-3,-4 option cards are orderable separately for field installation. Use WI-12174 and contact your SEL representative to order option cards.
- For relay wire termination kits, please see Application Note AN2014-08 on the SEL website or contact SEL REP or CSR for ordering information.
- For SEL-787-2,-3,-4 Mounting Accessories including adapter plates, dust protectors, etc go to <https://selinc.com/applications/mountingselector/>.
- ACSELERATOR Bay Screen Builder SEL-5036 software is available with touchscreen models.
- All Digital Outputs are Form-A unless noted otherwise.

Making Electric Power Safer, More Reliable, and More Economical®

SEL SCHWEITZER ENGINEERING LABORATORIES, INC.

2350 NE Hopkins Court - Pullman, WA 99163 USA
Phone: +1.509.332.1890 - Fax: +1.509.332.7990